## bodine

**Emergency Lighting** 

**Product Quick Guide** 

**BLK Retrofit Kits** 

# It's what to recommend when you don't know what to recommend!

"Will it fit?" may be the only question you need to ask\*



## **Emergency Lighting Retrofit Kits**

For more information, including ordering codes and additional product features and details, please see www.bodine.com/blk1000 and www.bodine.com/blk1000fl.

#### **BLK Driver**

- Integral Battery
- · CEC Title 20
- STSelect or FirstLink (BLK1000 or BLK1000FL)
- Low Profile Dimensions (14.1"L x 1.18"W x 1.0"H)

#### **LED Module**

- Provides more than 1000 lumens from the driver
- Dimensions 5.0" x 1.0"

#### **Illuminated Test Switch**

- Red/Green Bi-color, IP65, metal vandal resistant switch
- Plenum rated cable
- FirstLink communication node and mounting bracket (BLK1000FL only)

#### Installation Kit

- Plenum rated LED module wiring cable 37" long
- 18AWG solid copper AC mains wiring (black and white) - 27" long
- · Self drilling, panhead sheet metal screws x 4

#### **BLK1000**

STSelect - Enable or disable self-testing as needed. www.bodine.com/stselect




#### BLK1000FL

FirstLink connectivity for fast and simple maintenance and code compliance.

www.bodine.com/firstlink



### Example Wiring Diagram (BLK1000)



## Remember:

Unlike an emergency LED driver or fluorescent emergency ballast, the BLK1000 driver and module wire to each other, and only to each other.

The existing luminaire components, be it fluorescent, LED, TLED, incandescent, or anything else, do not interface with the BLK1000. The only shared connection is the 120-277 Vac mains wiring.



© 2024 Signify Holding. All rights reserved. The information provided herein is subject to change, without notice. Signify does not give any representation or warranty as to the accuracy or completeness of the information included herein and shall not be liable for any action in reliance thereon. The information presented in this document is not intended as any commercial offer and does not form part of any quotation or contract, unless otherwise agreed by Signify.

Signify North America Corporation 400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807 Telephone: 855-486-2216

Signify Canada Ltd. 281 Hillmount Road, Markham, ON, Canada L6C 2S3 Telephone: 800-668-9008

All trademarks are owned by Signify Holding or their respective owners